Battery Replacement: SupraPlus® Wireless





open battery door.



Use hook end of tool to hook battery wires and pull toward open battery door until battery moves out from behind post.



Once battery is removed, gently disconnect battery connector; do not pull hard.



battery into compartment, please be sure battery wires are on side closest to opened battery door; the battery cannot be installed properly if wires are on other side.



press the battery backwards and away from battery door until the left corner of the battery tucks under the post in the battery compartment. Tuck all of the battery wires and connectors into the battery compartment.



© 2006 Plantronics, Inc. All rights reserved. Plantronics, the logo design, Plantronics Sound Innovation, and SupraPlus are trademarks or registered trademarks of Plantronics, Inc.

Printed in USA

72942-01 [01.06]